#### **CONTROL PANEL OVERVIEW:**

- Increase Temperature: Button to raise temperature setting.
- Decrease Temperature: Button to lower temperature setting.
- **Display Screen:** Shows current settings and temperature.
- **Power/Standby Button:** Toggles between on and standby modes.
- Timer Function: Sets the duration for the heater operation.

#### LOCATION AND CONNECTION:

- Ensure at least 20 inches of space around the heater for proper airflow.
- Inspect the heater for any damage before use. If you notice any issues, contact our customer support.



CE COPLAR

For any questions, concerns, or issues with your **Power Pro Genius Heater**, please don't hesitate to reach out to our customer support team. We're here to help!

Contact us at *support@powerprogenius.com*, and we'll assist you with troubleshooting, product inquiries, or any necessary repairs or replacements.

Your satisfaction is our priority!



# HEATER USER GUIDE





#### **KEY BENEFITS:**

**Bright LED Display** Easy-to-read display for temperature settings and timer.

**Auto Shut-Off** Reduces power usage by automatically turning off when the desired temperature is reached.

- Temperature Range: 60°F to 90°F (15°C to 32°C)
  Adjustable for personalized comfort.
- Efficient PTC Ceramic Heating Element
  Provides rapid, energy-efficient warmth while lowering energy consumption.

\_\_\_\_\_

.....

• 500W Power

Delivers effective heating with minimal energy consumption.

- 1-12 Hour Timer Function & 2 Speed Settings
  Customize your heating schedule and fan speed for optimal comfort.
- 180° Rotatable Plug

Allows flexible, space-saving wall outlet use.

#### **HEATER COMPONENTS:**

- Fan Grid: Ventilation area for air circulation.
- **PTC Heating Element:** Core heating element.
- Back Grid: Rear ventilation or protection grid.
- Main Power Switch: Turns the heater on/off.
- Control Panel: Interface for adjusting settings.
- Power Plug:
  Used to connect the device to an electrical outlet.
- Indicator Light: Shows operational status.

## WHY CHOOSE POWER PRO GENIUS HEATER?

This compact, lightweight heater is perfect for any room or travel, offering reliable and energy-efficient warmth. Save on energy costs with its auto shut-off and adjustable temperature controls, while enjoying hassle-free heating wherever you are.

## **GENERAL SAFETY INSTRUCTIONS:**

• Keep Away from Children:

This appliance is not a toy. Supervise children during use.

• Burn Risk:

Avoid touching the heater's hot surface. Use handles or wait until it cools before moving.

• Avoid Fire Hazards:

Do not block air intake or discharge. Ensure all flammable objects are kept at least 24 inches (61 cm) away from the heater at all times.

• Electrical Safety:

Unplug the heater when not in use, and avoid using it while sleeping or unattended.



# HOW TO USE

• Plug in the Heater:

Plug the heater into a 110-125V/50Hz socket. Ensure it is switched off before plugging it in.

• Turn On the Heater:

Set the main switch to "I" (On) to enter standby mode. Press the ON/STANDBY button to activate the heater.



• Temperature Control:

The default maximum temperature is 90°F (32°C). Use the Temp Up/Down buttons to adjust the desired temperature (between 60°F and 90°F). The thermostat will maintain your set temperature.

• Fan Speed:

Press Temp Up and Temp Down simultaneously to toggle between low (LL) and high (HH) fan speeds.

#### • Timer Function:

Set the timer (up to 12 hours) using the Timer button. The display will show the number of hours before automatic shut-off.

Shut Down:

Press the ON/STANDBY button to stop heating. The fan will continue running for 60 seconds to cool down before fully shutting off. Use the main switch to turn the heater off completely.

# **SAFETY FEATURES:**

- **Overheat Protection:** The heater will automatically shut off if it overheats. Unplug, cool down, and remove any obstructions before resuming use.
- **Auto Shut-Off:** The heater turns off when the set temperature is reached to save energy.

#### **DISPOSAL INSTRUCTIONS:**

• Proper Disposal:

Do not dispose of the heater as household waste. Take it to a local recycling facility.